

How to locate the chuff adjuster




1. Open the front cylinder cover (both sides).
2. Move the cross head until find out the chuff adjuster inside the cylinder.
3. Adjust the position of the chuff adjuster.



How to access the interface circuit board




To locate the switches of the motor, the polarity, the electric pick up & chuff inside the tender



BACHMANN INDUSTRIES, INC.
1400 East Erie Avenue
Philadelphia, Pennsylvania 19124 USA
800-356-3910
www.bachmanntrains.com
Printed in China

How to separate the gear box from the chassis



1. Unfasten 2 screws from motor holder.
2. Unfasten 4 screws from the gear box cover (under the chassis).
3. Remove the gear box cover.
4. Pull up the gear box with the motor.

BACHMANN INDUSTRIES, INC.
1400 East Erie Avenue
Philadelphia, Pennsylvania 19124 USA
800-356-3910
www.bachmanntrains.com
Printed in China

Wiring Assembly Diagram

1:20.3 Large Scale

C-19

